





centor®





## Centor LT installation instructions

centor®  
*Moved by Innovation*



# A

# Lockcalc LT LA.xls



[www.centor.eu](http://www.centor.eu)



[www.centorusa.com](http://www.centorusa.com)




[www.centor.com.au](http://www.centor.com.au)





# B

centor<sup>®</sup>






= Lockcalc LT LA.xls














Centor E2







Centor E3






THO	
4mm (5/32")	Lockcalc LT LA.xls 
11mm (7/16")	
12mm (15/32")	
15mm (19/32")	





Lockcalc LT LA.xls

















# D

centor®














# E

centor<sup>®</sup>







X=	
20mm (25/32")	Lockcalc LT LA.xls 
30mm (1 3/16")	





# F


centor<sup>®</sup>
























**Centor Europe**

+44 (0)121 701 2500

[mail@centor.eu](mailto:mail@centor.eu)

[www.centor.eu](http://www.centor.eu)

**Centor North America**

+1 630 957 1000

[mail@centorusa.com.au](mailto:mail@centorusa.com.au)

[www.centorusa.com.au](http://www.centorusa.com.au)

**Centor Asia Pacific**

1300 CENTOR

[mail@centor.com.au](mailto:mail@centor.com.au)

[www.centor.com.au](http://www.centor.com.au)